

INSTALLATION GUIDE

Product description:

This part replaces OEM part number 60570627.
Part fits Alfa Romeo GTV model year 1995 - 2002.

Contents (parts per pack):

2 x Bushes 2 x Stainless steel sleeves 4x Washers
1 x Grease



*Please read the complete fitting instructions and check package components before fitment.
These fitting instructions are to be used as a guide and in conjunction with workshop manual.
It is recommended that:*

- all work to be carried out by a licensed technician;
 - all safety precautions adhered to;
 - wheel alignment to be checked and adjusted as required after any suspension work.
- All fasteners must be tensioned to manufacturer's torque settings.*

Fitting Instructions:

1. Undo the nut from the link rod and separate from the anti roll bar.
2. Drill the swedged washers on the link rod and push the rubber bush out, as shown in Fig A.
2. Clean any dirt, corrosion and remove any sharp edges from the inside of the bracket. Push bush into the bore.
3. Apply some of the supplied grease to the bore of the bush. Insert stainless steel sleeve into the bore of the bush. Fig B.
4. Use supplied washers and re-fit link rod back to the anti roll bar. Tension all hardware to manufacturers recommended torque settings.



Fig A.



Fig B.