



PART NUMBER

PFF19-1302G

DESCRIPTION

FRONT ARM REAR BUSH - CASTER ADJUST

INSTALLATION GUIDE

Product description:

Polyurethane low compliance ball and socket style bush with on car adjustable caster allowing +/- 0.33 degrees of static adjustment.

Contents (parts per pack):

2 x bushes

Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;
 - all safety precautions adhered to;
 - wheel alignment to be checked and adjusted as required after any suspension work.
- All fasteners must be tensioned to manufacturer's torque settings.*

Fitting Instructions:

1. Remove the front lower arm, remove the original rear bush from the arm.
2. Clean any rust and dirt from the arm.
3. Press the bush into the arm leaving an equal amount of the bush each side of the arm, the end with the flats is the upper side.
4. It is advisable to orientate the bush to give maximum caster adjustment before refitting the arm.
5. Refit the arm to the car.
6. Carry out alignment adjustments and road test.

