

INSTALLATION GUIDE

Contents (parts per pack):

- 1 x Polyurethane A Insert
- 2 x Polyurethane B Insert

Please read the complete fitting instructions and check package components before fitment.

These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;
- all safety precautions adhered to;
- wheel alignment to be checked and adjusted as required after any suspension work.

All fasteners must be tensioned to manufacturer's torque settings.



Fitting Instructions:

Note: It should not be necessary to remove the engine mount from the vehicle

1. Clean any dirt and corrosion from the bores in the mount.
2. Fit polyurethane A insert into the engine mount bush, from the right hand side of the vehicle. As shown in Figure 1.
3. Insert each polyurethane B insert into holes at the top of polyurethane A insert, making sure the arrows with 'UP' inscribed on to it are facing upwards on vehicle. As shown in Figure 1.
4. Re-fit engine mount to the vehicle. Tension all hardware to manufacturers recommended torque settings.




Figure 1: Fitted Assembly Steps