

# POWERFLEX®

PART NUMBER

**PFF25-302**

DESCRIPTION

**FRONT ARM REAR BUSH**

## INSTALLATION GUIDE

### Contents (parts per pack):

- 4 x bushes (2 x A parts, 2 x B parts)
- 2 x stainless steel sleeves
- 1 x grease

*Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.*

*It is recommended that:*

- all work to be carried out by a licensed technician;
- all safety precautions adhered to;
- wheel alignment to be checked and adjusted as required after any suspension work.

*All fasteners must be tensioned to manufacturer's torque settings.*

### Fitting Instructions:

1. Remove the arm from the car.
2. Remove the original bush from the arm, clean any dirt and rust away.
3. Fit the A bush in from the front and the B part in from the rear.
4. Apply some of the supplied grease to the bore of the bush and end faces.
5. Push the sleeve into the bush.
6. Refit the arm to the car.

