

INSTALLATION GUIDE

Contents (parts per pack):

2 x Polyurethane A bush	2 x Sleeves
2 x Polyurethane B bush	4 x Washers
1X Grease	

Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual. It is recommended that:

- all work to be carried out by a licensed technician;*
 - all safety precautions adhered to;*
 - wheel alignment to be checked and adjusted as required after any suspension work.*
- All fasteners must be tensioned to manufacturer's torque settings.*

Fitting Instructions:

1. Remove the original bush from the bracket.
2. Clean any dirt and corrosion from the bore in the bracket. Remove any sharp edges from the bore of the arm.
3. Insert A bushes into bracket on the side with no features.
4. Insert B bush into bracket with side with features, ensuring the clipped lip is over bracket features.
5. Apply grease into bore of the bushes.
6. Fit sleeve into bush.
7. Washers should be fitted on the outside of the top hats in cut out hole with the flush face against the polyurethane bush.
8. Refit arm.

