



PART NUMBER
PFF27-203

DESCRIPTION
FRONT LOWER WISHBONE FRONT BUSH

INSTALLATION GUIDE

Contents (parts per pack):

- 4 x bushes, 2 x A bushes & 2 x B bushes.
- 2 x metal sleeves
- 1 x grease

Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual. It is recommended that:

- all work to be carried out by a licensed technician;
- all safety precautions adhered to;
- wheel alignment to be checked and adjusted as required after any suspension work.

All fasteners must be tensioned to manufacturer's torque settings.

Fitting Instructions:

1. Remove the lower arm, before removing the bush from the arm take a note of the original bush offset.
2. Remove the front bush from the arm and clean any rust and dirt from the arm.
3. Fit the A bush with the thicker larger diameter into the side of the arm which had the greater offset. Fit the thinner B bush into the other side of the arm.
4. Apply some of the supplied grease to the bore of the bush and the outside of the sleeve, push the sleeve into the bush.
5. Refit the arm to the car.



A bush



B bush