

INSTALLATION GUIDE

Product description:

This part fits OEM part number 3C254 & 3C255

Contents (parts per pack):

2 x Polyurethane Bushes 2 x Stainless steel sleeves 1 x Grease

Please read the complete fitting instructions and check package components before fitment.

These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

-all work to be carried out by a licensed technician;

-all safety precautions adhered to;

-wheel alignment to be checked and adjusted as required after any suspension work.

All fasteners must be tensioned to manufacturer's torque settings.



Fitting Instructions:

1. Remove the front lower track control arm from the car and remove the original outer bush from the arm.
2. File down the sharp edges from the bore on both sides of the arm and clean the bore of any dirt and debris. Fig. A
3. Apply some washing up liquid around the edges and inside the bore of the arm.
4. Push the new PU bush into the bore of the arm. Fig. B
5. Apply some of the supplied grease into the bore of the bush and insert the stainless steel into the bore. Fig. b
6. Ref t arm back to the car and tension all hardware to manufacturers recommended torque settings.

Fig A




Fig B

