



PART NUMBER

PFF3-213

DESCRIPTION

FRONT ANTI ROLL BAR LINK ROD BUSH

INSTALLATION GUIDE

Product description:

PFF3-213 Replaces the bush in the alloy bracket which joins the front anti roll bar to the lower arm, it will not fit the bracket which has a ball joint at each end.

Contents (parts per pack):

- 4 x bushes
- 4 x metal sleeves
- 4 x washers
- 1 x grease

Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;*
 - all safety precautions adhered to;*
 - wheel alignment to be checked and adjusted as required after any suspension work.*
- All fasteners must be tensioned to manufacturer's torque settings.*

Fitting Instructions:

1. Remove the bracket from the car.
2. Remove original bushes from the bracket, clean the bore of the bracket.
3. Lubricate the out side of the new bush with washing up liquid and push into the bracket, *tip hold the bush at an angle to the bracket to get the bush started in the hole.*
4. Apply some of the supplied grease to the bore of the bush and push the stainless steel sleeve through
5. Bolt the bracket back onto the anti roll bar and lower arm fitting the washer to the free face of each bush

