

**PART NUMBER****PFF3-705****DESCRIPTION****FRONT LOWER SHOCK BUSH****INSTALLATION GUIDE****Contents (parts per pack):**

- | | |
|----------------------------|-----------------|
| 4 x Polyurethane bush | 2 x Outer shell |
| 2 x Stainless steel sleeve | 1 x Grease |

Please read the complete fitting instructions and check package components before fitment.

These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;*
- all safety precautions adhered to;*
- wheel alignment to be checked and adjusted as required after any suspension work.*

All fasteners must be tensioned to manufacturer's torque settings.

**Fitting Instructions:**

1. Remove the original bush from the arm.
2. Clean any dirt and corrosion from the bore in the arm. Remove any sharp edges from the bore of the arm.
3. Press the shell into the arm so the ridge fits flush with arm.
Note: The orientation of the shell does not affect performance.
4. Insert each polyurethane bush into bore of the outer shell, with lipped face facing outwards.
5. Apply grease into bore of the polyurethane bush.
6. Fit the stainless steel sleeve into bush.
- 7 Re-fit arm to the car. Tension all hardware to manufacturers recommended torque settings.

