



PART NUMBER

PFF30-322

DESCRIPTION

ENGINE MOUNT LARGE BUSH

INSTALLATION GUIDE

Contents (parts per pack):

2 x Polyurethane Bushes 1 x Stainless Steel Sleeve
2 x Steel Washers 1 x Grease

Please read the complete fitting instructions and check package components before use. These fitting instructions are to be used as a guide and in conjunction with workshop manuals. It is recommended that:

- all work to be carried out by a licensed technician;
 - all safety precautions adhered to;
 - wheel alignment to be checked and adjusted as required after any suspension work.
- All fasteners must be tensioned to manufacturer's torque settings.*



Fitting Instructions:

1. Remove the original bush from the bracket.
2. Clean any dirt and corrosion from the bore in the bracket. Remove any sharp edges from the bore of the bracket.
3. Place the steel washers onto the inside lip of the polyurethane bushes.
4. Push polyurethane bushes into bore of the bracket. Make sure the off centered hole is towards the ribbed side of the bracket; as shown in figure 1.
5. Apply some of the supplied grease to the bore and end faces of the bush, push the stainless steel sleeve into the offcentered bush bore.
6. Re-fit arm to the car. Tension all hardware to manufacturers recommended torque settings.

