

INSTALLATION GUIDE

Contents (parts per pack):

4x Inserts 1 x Grease

Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;*
 - all safety precautions adhered to;*
 - wheel alignment to be checked and adjusted as required after any suspension work.*
- All fasteners must be tensioned to manufacturer's torque settings.*



Fitting Instructions:

1. Gain access to the front lower arm rear bush.
2. Clean any dirt or debris from around the rubber bush and voidings. Apply some of the supplied grease on the inner and outer face of the inserts.
3. Position the slot features on the inserts to match the locating features on the rubber bush. Fig A.
4. Fit insert from both sides. Fig B.
5. Refit arm onto the car and tension all hardware to manufacturers recommended torque settings.




Fig A.



Fig B.