

POWERFLEX®

PART NUMBER

PFF5-601

DESCRIPTION

FRONT LOWER TIE BAR TO CHASSIS BUSH

INSTALLATION GUIDE

FITS BMW E34 5 SERIES (1988-1996) & E32 7 SERIES (1988-1994)

Contents (parts per pack):

- 2 x bushes
- 2 x stainless steel sleeves
- 2 x washers
- 1 x grease

Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;
- all safety precautions adhered to;
- wheel alignment to be checked and adjusted as required after any suspension work.

All fasteners must be tensioned to manufacturer's torque settings.

Fitting Instructions:

1. Remove the original bush from the arm, this can be carried out either by leaving the arm on the car if you have a puller or remove the arm from the car and press the bush out.
2. Clean any dirt and corrosion from the arm.
3. Before fitting the new bush please note one end is longer than the other. The longer end fits against the flat plate of the subframe, the shorter side faces the tube on the subframe.
4. To help installation of the new bush smear washing up liquid around the lip and place the bush into the hole of the arm at an angle so one part of the lip is already in the hole. With either the puller or press insert the bush into the arm.
5. Apply some of the supplied grease to the bore of the bush and outside of the sleeve, push the sleeve into the bush.
6. Refit the arm back into position, before refitting the bolt fit the washer in between the shorter end of the bush and the tube of the subframe. Fit the bolt and tighten.

