



PART NUMBER

PFF57-802

DESCRIPTION

FRONT CONTROL ARM OUTER BUSH

INSTALLATION GUIDE

Product description:

PFF57-802 ALLOWS ON CAR ADJUSTMENT OF THE CASTER ANGLE.

Contents (parts per pack):

- 4 x bushes (2 x A part & 2 x B part)
- 2 x aluminium adjustable sleeves
- 1 x C spanner
- 1 x grease



*Please read the complete fitting instructions and check package components before fitment.
These fitting instructions are to be used as a guide and in conjunction with workshop manual.
It is recommended that:*

- all work to be carried out by a licensed technician;
- all safety precautions adhered to;
- wheel alignment to be checked and adjusted as required after any suspension work.

All fasteners must be tensioned to manufacturer's torque settings.

Fitting Instructions:

1. Remove the front control arm, remove the outer bush front the arm, clean the arm of any dirt and corrosion.
2. Fit 1 A & 1 B part bush into the arm, lubricate the bore and end faces of the bushes with some of the supplied grease.
3. Fit the sleeve into the bush, the end with the adjustment wheel fits against the A bush with the thinner top section.
4. Use the central hole if standard caster is required, use the offset hole if PFF57-801 has been fitted to the car or if caster adjustment is required.
5. Refit the arm to the car, carry out alignment check. If the caster requires adjustment slacken the bolt, adjust the caster to the desired setting with the C spanner, re tighten the bolt and recheck alignment.

