

POWERFLEX®

PART NUMBER

PFF60-1702

DESCRIPTION

FRONT ARM REAR BUSH

INSTALLATION GUIDE

Product description:

This polyurethane bush fits into the rear position of the front arm. It is designed to complement PFF60-1701 that fits into the front position of the arm.

Contents (parts per pack):

- 2 x Polyurethane bushes
- 2 x Zinc plated outer shells
- 2 x Stainless steel sleeves
- 1 x Grease



Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;*
- all safety precautions adhered to;*
- wheel alignment to be checked and adjusted as required after any suspension work.*

All fasteners must be tensioned to manufacturer's torque settings.

Fitting Instructions:

1. Remove the original rubber bush from the arm, clean any dust and corrosion from the bore in the arm. With a file remove any sharp edges from the bore of the arm.
2. Press the outer shell into the arm from the radius side, until the larger diameter of the shell sits against the arm.
3. Push in the polyurethane bush into the shell. It may be necessary to apply some washing up liquid to the outside of the bush to ease fitting. In some cases it may be easier to insert the bush into the arm at an angle.
4. Apply some of the supplied grease to the bore of the bush and insert the sleeve.
5. Re-fit the arm to the car and tension all hardware to manufacturers recommended torque settings.

