



PART NUMBER

**PFF60-502**

DESCRIPTION

**FRONT ARM REAR BUSH**

### INSTALLATION GUIDE

#### **Product description:**

This polyurethane bush fits into the rear position of the front arm. It is designed to complement PFF60-501 that fits into the front position of the arm.

#### **Contents (parts per pack):**

- 2 x Polyurethane bushes
- 2 x Aluminium outer shells
- 2 x Stainless steel sleeves
- 1 x Grease



*Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.*

*It is recommended that:*

- all work to be carried out by a licensed technician;
- all safety precautions adhered to;
- wheel alignment to be checked and adjusted as required after any suspension work.

*All fasteners must be tensioned to manufacturer's torque settings.*

#### **Fitting Instructions:**

1. Remove the original rubber bush from the arm, clean any dust and corrosion from the bore in the arm. With a file remove any sharp edges from the bore of the arm.
2. Press the aluminium outer shell into the arm from the top side, until the larger diameter of the shell sits against the arm.
3. Push in the polyurethane bush into the shell with the smallest end of the bush entering the shell first. It may be necessary to apply some washing up liquid to the outside of the bush to ease fitting. In some cases it may be easier to insert the bush into the arm at an angle.
4. Apply some of the supplied grease to the bore of the bush and insert the sleeve.
5. Re-fit the arm to the car and tension all hardware to manufacturers recommended

