



PART NUMBER

PFF60-525

DESCRIPTION

GEARBOX MOUNTING BUSH INSERT

INSTALLATION GUIDE

Product description:

This polyurethane insert fits into and fills voids in the original rubber bush, OE part number: 8200352861 (Renault) and 11220-BN720 (Nissan). It is designed to limit movement of the engine and gearbox to provide additional stability under acceleration.

Contents (parts per pack):

- 1 x Polyurethane A bush
- 1 x Polyurethane B bush

Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;
- all safety precautions adhered to;
- wheel alignment to be checked and adjusted as required after any suspension work.

All fasteners must be tensioned to manufacturer's torque settings.

Fitting Instructions:

1. Remove the gearbox mount from the car and remove the mounting bolts.
2. Insert the smaller A part polyurethane insert into the base of the original rubber bush. This replaces the small rubber washer inside the original bush.
3. To fit the larger B part polyurethane insert, fit the flexible legs into the holes in the top part of the rubber bush and pull the insert over the lip on the rubber bush.
4. Re-assemble the gearbox mount and tension all hardware to manufacturers recommended torque settings.

