



Fitting Instructions

PFF76-402K

Toyota Starlet EP82-92 Anti Lift Kit

1. Remove front wishbone, then remove rear bush.
2. Fit the polyurethane bush onto the rear pin of the wishbone making sure the hole is off centre to the outside of the car to give the gain in caster.
3. Refit the wishbone to the car.
4. Fit the supplied U bracket over the bush, place the supplied aluminium spacer bar between the car and the U bracket .
5. Using the new supplied bolts and washers, tighten to manufactures specification.
6. Once vehicle has been road tested carry out wheel alignment checks. The U bracket and spacer bar holes are slotted to allow for adjustments.1 KIT SHOW BELOW.

