

# POWERFLEX®

PART NUMBER

**PFF80-1201**

DESCRIPTION

**FRONT LOWER ARM - FRONT BUSH**

## INSTALLATION GUIDE

### Contents (parts per pack):

- 4 x bushes (2 x A parts & 2 x B parts)
- 2 x stainless steel sleeves
- 1 x grease



*Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual. It is recommended that:*

- all work to be carried out by a licensed technician;
  - all safety precautions adhered to;
  - wheel alignment to be checked and adjusted as required after any suspension work.
- All fasteners must be tensioned to manufacturer's torque settings.*

### Fitting Instructions:

1. Remove front lower arm from the car.
2. Remove the original rubber bush from the arm.
3. Clean any corrosion, dirt or burrs from the hole.
4. Each bush consists of 1 x 80-1201A polyurethane bush, 1 x 80-1201B polyurethane bush and 1 x stainless steel sleeve
5. The bush marked 80-1201A has a narrower top section and fits in from the front of the arm. 80-1201B has a thicker top section and fits in from the rear of the arm.
6. Once the bushes have been fitted apply some of the supplied grease to the bore and the end faces of the bushes.
7. Insert the stainless steel sleeve through the bush.
8. Refit the arm to the car.

