



**Fitting Instructions For PFF88-106
Volvo 850, V70, C70 & S70 upto 2000**

- 1. Remove bush and bracket assembly from the car.**
- 2. Cut or burn the original rubber and central sleeve out of the bush leaving the outer sleeve attached to the bracket. Make sure you remove all the old rubber form inside the original metal outer sleeve.**
- 3. Insert the new Powerflex Polyurethane parts into the original outer sleeve, apply some of the supplied grease into the central hole and around the outside of the stainless steel sleeve and push the sleeve into the bush.**
- 4. Refit the bracket and Powerflex bush back onto the car and tighten the bolts to the manufactures specifications.**



**Should you experience any technical difficulties in any way please
contact our technical Hotline 01895 460033,
Or email us at sales@powerflex.co.uk**