

POWERFLEX®

PART NUMBER

PFF88-202

DESCRIPTION

FRONT ARM REAR BUSH

INSTALLATION GUIDE

Contents (parts per pack):

- 2 x bushes
- 2 x outer shells
- 2 x stainless steel sleeves
- 1 x grease



Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;
- all safety precautions adhered to;
- wheel alignment to be checked and adjusted as required after any suspension work.

All fasteners must be tensioned to manufacturer's torque settings.

Fitting Instructions:

1. Remove the front arm and front arm rear bush bracket from the car.
2. Undo the rear securing bolt from the pin going through the rear bush, and slide off the rear bush and bracket.
3. Carefully press out the bush from the bracket, clean any dirt and rust away.
4. Press the new outer shell back into the bracket, larger face towards the front of the car.
5. Push the new bush into the shell, apply some washing up liquid to help, insert the smaller end of the bush in from the front, larger, end of the shell, making sure the bush pops all the way through.
6. Apply some of the supplied grease to the bore of the bush and outside of the sleeve, push the sleeve into the bush.
7. Fit the bush and bracket back onto the arm, replace the nut and washer, tighten to manufacturers torque setting.
8. Refit the arm back onto the car.

For fitting videos go to youtube.com/powerflexptg

