

POWERFLEX®

PART NUMBER

PFF88-601

DESCRIPTION

FRONT LOWER WISHBONE FRONT BUSH

INSTALLATION GUIDE

Product description:

PFF88-601 is a complete assembly that includes a replacement sleeve, outer shell and polyurethane bush, replacing OE numbers: 9465971 and 9443882.

Contents (parts per pack):

2 x Polyurethane bush assemblies
1 x PTFE / Silicone Bush Assembly Grease



Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual. It is recommended that:

- all work to be carried out by a licensed technician;*
 - all safety precautions adhered to;*
 - wheel alignment to be checked and adjusted as required after any suspension work.*
- All fasteners must be tensioned to manufacturer's torque settings.*

Fitting Instructions:

1. Remove original bush and original steel outer shell from the arm, clean any dirt and corrosion from the bore in the arm. Using file remove any sharp edges from the bore of the arm.
2. Push in the new bush into the arm from the front of the car until the largest diameter of the outer shell sits against the machined face of the arm.
Note: it is important to press the bush in using the outer shell only, avoiding contact with the sleeve - it may be necessary to use a section of tube or socket to help this.
4. Re-fit the arm to the car and tension all hardware to manufacturers recommended torque settings.

