



PART NUMBER

PFR12-610

DESCRIPTION

REAR BEAM MOUNTING BUSH

INSTALLATION GUIDE

Product description:

This part replaces the bush with the OEM part numbers:
5131 F2 & 5131 H2.

Contents (parts per pack):

2 x Polyurethane bushes 2 x Stainless steel sleeves
1 x Grease

Please read the complete fitting instructions and check package components before fitment.

These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;*
 - all safety precautions adhered to;*
 - wheel alignment to be checked and adjusted as required after any suspension work.*
- All fasteners must be tensioned to manufacturer's torque settings.*



Fitting Instructions:

1. Remove the original bush from the rear beam mount.
2. Clean any dirt and corrosion from the bore in the arm. Remove any sharp edges from the bore of the rear beam mount.
3. Insert bushes into arm with larger diameter lip face facing towards centre of car.
4. Apply grease into bore of the bushes.
5. Fit sleeve into bush.
6. Washers should be fitted to the outside of the top hats on the larger lip face on the inner side of the bracket to the support the bush.
7. Refit rear beam mount.

