



PART NUMBER

**PFR19-810G**

DESCRIPTION

REAR UPPER CONTROL ARM CAMBER ADJUSTABLE BUSH

INSTALLATION GUIDE

**Product description:**

This polyurethane bush fits into the rear upper control arm and is designed to give +/- 1 degrees of on-car camber adjustment.

**Contents (parts per pack):**

- 8 x Polyurethane bushes
- 2 x Zinc plated steel shells
- 2 x Stainless steel adjustable sleeves
- 1 x C spanner
- 1 x Grease



*Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.*

*It is recommended that:*

- all work to be carried out by a licensed technician;
- all safety precautions adhered to;
- wheel alignment to be checked and adjusted as required after any suspension work.

*All fasteners must be tensioned to manufacturer's torque settings.*

**Fitting Instructions:**

1. Remove the original rubber bush from the arm, clean any dirt and corrosion from the bore in the arm.
2. Press the outer shell into the arm, until the smallest diameter meets the end of the flat face of the arm.
3. Push each polyurethane bush into each side of the shell until it meets the shell.
4. Apply some of the supplied grease to the bore of the bush, insert the sleeve into the bush until it meets the bush.
5. Refit the arm to the car, carry out alignment check and adjust to set desired geometry using the supplied c-spanner.
6. Drive the car to settle the suspension and adjust the geometry to required setting.



Sleeves adjusted to give maximum positive camber



Sleeves adjusted to give maximum negative camber