

### INSTALLATION GUIDE

#### Contents (parts per pack):

2 x Polyurethane bushes  
1 x Grease

2 x Stainless steel sleeves  
4 x Washers



*Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.*

*It is recommended that:*

- all work to be carried out by a licensed technician;*
  - all safety precautions adhered to;*
  - wheel alignment to be checked and adjusted as required after any suspension work.*
- All fasteners must be tensioned to manufacturer's torque settings.*

#### Fitting Instructions:

1. Remove the original bush from the arm.
2. Clean any dirt and corrosion from the bore in the arm. Remove any sharp edges from the bore of the arm.
3. Press bush into the arm, Make sure the shoulder of the outer shell meets the machined faced.
4. Apply some of the supplied grease to the bore and end faces of the bush, push the stainless steel inner sleeve into the bush and place washers on both sides of the bush.
5. Re-fit arm to the car. Tension all hardware to manufacturers recommended torque settings.

