



PART NUMBER

**PFR3-743**

DESCRIPTION

**REAR DIFF REAR BUSH INSERT**

INSTALLATION GUIDE

**Product Description:**

This part inserts into the bush with the OEM number: 8K0 599 257 N

**Contents (parts per pack):**

- |                              |                   |
|------------------------------|-------------------|
| 2 x Polyurethane Bush insert | 2 x Steel Washers |
| 2 x Stainless steel sleeves  | 2 x M12 Washers   |
| 2 x M12 High tensile bolt    | 1 x Grease        |

Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;
- all safety precautions adhered to;
- wheel alignment to be checked and adjusted as required after any suspension work.
- All fasteners must be tensioned to manufacturer's torque settings.



**Fitting Instructions:**

1. Clean any dirt and corrosion from the inside of the original bush.
2. Insert the polyurethane bush insert into the original bush.
3. Insert the stainless steel sleeve into bore of polyurethane bush insert.
3. Apply some of the supplied grease to the bore and mounting faces of each bush and insert.
4. Fit the original washer onto the end of the bush assembly, followed by the supplied M12 washer and M12 bolt.

