

POWERFLEX®

PART NUMBER

PFR42-612

DESCRIPTION

Rear Trailing Arm Outer Bush

INSTALLATION GUIDE

Product description:

This part replaces OEM part number RGX000850

Contents (parts per pack):

- 2 x bushes
- 2 x stainless steel sleeves
- 1 x grease

Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;
- all safety precautions adhered to;
- wheel alignment to be checked and adjusted as required after any suspension work.

All fasteners must be tensioned to manufacturer's torque settings.

Fitting Instructions:

1. Remove the outer side bush from the rear trailing arm.
2. Fit the new bush A with bigger top diameter from the flat surface side of the arm and fit bush B with smaller top diameter from the other side of the arm.
3. Apply some of the supplied grease to the bore of the bush and insert the sleeve into the bush.
4. Re-fit the rear trailing arm to the car and tension all hardware to manufacturers recommended torque settings.

