



PART NUMBER

PFR46-410

DESCRIPTION

REAR DIFF MOUNT BUSH

INSTALLATION GUIDE

Product description:

This part replaces OEM part number 55401-RS590.

Contents (parts per pack):

2 x 'A' PU, 2 x 'B' PU, 2 x Stainless steel sleeves, 2 x Washers, 1 x Grease.

*Please read the complete fitting instructions and check package components before fitment.
These fitting instructions are to be used as a guide and in conjunction with workshop manual.*

It is recommended that:

- all work to be carried out by a licensed technician;*
 - all safety precautions adhered to;*
 - wheel alignment to be checked and adjusted as required after any suspension work.*
- All fasteners must be tensioned to manufacturer's torque settings.*

Fitting Instructions:

1. Remove the old bushes from the diff mounts.
2. Remove any sharp edges and clean any dirt or corrosion from the arm bore.
3. Insert the 'A' PU from the top of the mount and fit 'B' PU from the bottom of the mount.
4. Apply the supplied grease into the bore of PU bushes and insert the stainless steel sleeve into the bore of the bushes.
5. Use the original washer at the bottom of the mount and use the supplied washer from the top of the mount and refit the diff mount back to the chassis.
6. Tension all hardware to manufacturers recommended torque settings.

