

POWERFLEX®

PART NUMBER

PFF5-1313

DESCRIPTION

REAR LATERAL ARM INNER BUSH

INSTALLATION GUIDE

Product description:

Contents (parts per pack):

- 8 x bushes
- 4 x outer shells
- 4 x stainless steel sleeves
- 1 x grease



Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;
- all safety precautions adhered to;
- wheel alignment to be checked and adjusted as required after any suspension work.

All fasteners must be tensioned to manufacturer's torque settings.

Fitting Instructions:

1. Remove the arm from the car.
2. The original shell needs to be pressed out of the arm, take care not to deform/collapse the arm whilst doing this by using a spacer between the 2 sides.
3. Leaving the spacer between the arm press in the new outer shell so it fits centrally.
4. Fit the bushes into the outer shell.
5. Apply some of the supplied grease to the bore of the bush , push the stainless steel sleeve through the bush.
6. Refit arm to the car.

Fit spacers here to stop arm deforming while pressing shell.

