

POWERFLEX®

PART NUMBER

PFR5-2020

DESCRIPTION

Rear Beam Mount Bush Inserts

INSTALLATION GUIDE

Product description:

This part replaces OEM part number 33333428100.

Contents (parts per pack):

2 x A Inserts
2 x B Inserts

Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;
 - all safety precautions adhered to;
 - wheel alignment to be checked and adjusted as required after any suspension work.
- All fasteners must be tensioned to manufacturer's torque settings.*

Fitting Instructions:

1. Lower one side of the Rear Beam. Undo the Lower bracket from the mount.
2. Clean any dirt from the rubber bush from both top and bottom voids.
3. Slide the new 'A' Insert into the voids from the top of the mount and 'B' Insert into the voids from the bottom of the mount. Fig A. Repeat same on the other side of the beam.
4. Fig B. shows the Dished face of Bush 'B' which fits into the Bottom side voids of the Mount.
5. Re-fit the lower bracket back on the mount. Tension all hardware to manufacturers recommended torque settings.

