

POWERFLEX®

PART NUMBER

PFR5-324

DESCRIPTION

E36 M3 EVO REAR DIFF FRONT MOUNTING BUSH

INSTALLATION GUIDE

Product description:

This polyurethane bush offers reduced movement of the rear diff which results in a reduction in the initial torque lost during acceleration. It is design to complement 5-326 that fits into the rear mounting bracket.

Contents (parts per pack):

- 1 x Polyurethane A bush
- 1 x Polyurethane B bush
- 2 x Steel zinc plated steel washers
- 1 x Stainless steel sleeve
- 1 x Grease



Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual. It is recommended that:

- all work to be carried out by a licensed technician;
 - all safety precautions adhered to;
 - wheel alignment to be checked and adjusted as required after any suspension work.
- All fasteners must be tensioned to manufacturer's torque settings.*

Fitting Instructions:

1. Remove the original rubber bush from the bracket. Clean any dirt or corrosion from the bore of the bracket and mounting faces of the diff.
2. Fit the A part of the bush into the bracket from the rear of the car. Fit the B part of the bush into the bracket from the front of the car.
3. Apply some of the supplied grease to the bore and both ends of each bush and insert the sleeve into the bush.
4. Place washers on each side of the bush, re-fit the bracket to the car and tighten bolts to manufacturers recommended torque settings.



**Front of car
(B Bush)**



**Rear of car
(A Bush)**