

**PART NUMBER****PFR5-4026****DESCRIPTION**

REAR DIFF REAR MOUNTING BUSH

INSTALLATION GUIDE**Product description:**

This part replaces OE number: 33177852495.

Contents (parts per pack):

- 1 x Polyurethane A Bush
- 1 x Polyurethane B Bush
- 1 x Aluminium Sleeve
- 1 x PTFE / Silicone Bush Assembly Grease

Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;*
 - all safety precautions adhered to;*
 - wheel alignment to be checked and adjusted as required after any suspension work.*
- All fasteners must be tensioned to manufacturer's torque settings.*

Fitting Instructions:

1. Remove the original rubber bush from rear diff rear mounting position in the subframe.
2. Push the new A part polyurethane bush into the bore of the subframe from the rear of the car. Push the new B part polyurethane bush into the bore of the subframe from the front of the car.
3. Apply the supplied PTFE / Silicone grease to the bore and mounting faces of the bush and insert the sleeve into the A bush from the rear of the car.
4. Re-fit the diff to the car and tension all hardware to manufacturers recommended torque settings.

