



PART NUMBER

PFR5-4611

DESCRIPTION

REAR SUBFRAME REAR BUSH

INSTALLATION GUIDE

Product description:

These bushes give a positive location of the rear sub frame, reducing movement at the rear end under cornering.

Contents (parts per pack):

2 x bushes (2 x A Upper parts & 2 x B Lower parts)

2 x metal sleeves

1 x grease

Please read the complete fitting instructions and check package components before fitment.

These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;

- all safety precautions adhered to;

- wheel alignment to be checked and adjusted as required after any suspension work.

All fasteners must be tensioned to manufacturer's torque settings.

Fitting Instructions:

1. Remove original bush. Clean sub frame of any rust and dirt.
2. Fit the upper part PFR5-4611A into the sub frame from the upper chassis side. (Also identified by a groove in the upper face)
3. Fit the lower part PFR5-4611B into the sub frame from the lower (road) side. (Also identified by a recess in the middle of the lower face)
4. Apply the supplied grease to the bore of the bush, the outside of the stainless steel sleeve and the upper and lower faces of the bush.
5. Push the stainless steel sleeve into the bush.
6. Refit using the original bolt and washer, tightening to manufactures recommended torque settings.

