



PART NUMBER

PFR5-5630-10

DESCRIPTION

REAR SHOCK TOP MOUNT BRACKET AND BUSH

INSTALLATION GUIDE

Product description:

The bracket and bush replaces the original top mount assembly, where it has a 10mm pin on the shock absorber. This bush offers a quality, reliable replacement.

Contents (parts per pack):

- 4 x bushes
- 2 x stainless steel sleeves
- 2 x aluminium brackets with studs and nuts
- 2 x strengthening plates
- 1 x grease



*Please read the complete fitting instructions and check package components before fitment.
 These fitting instructions are to be used as a guide and in conjunction with workshop manual.
 It is recommended that:*

- all work to be carried out by a licensed technician;
 - all safety precautions adhered to;
 - wheel alignment to be checked and adjusted as required after any suspension work.
- All fasteners must be tensioned to manufacturer's torque settings.*

Fitting Instructions:

1. Remove the original rear shock top mount from the car and shock absorber. The original washers either side of the mount need to be kept as they are reused.
2. Reassemble the top mount, the bracket fits from the underside with the studs going up through the panel. Apply some of the supplied grease to the bore of the bush and inset the sleeve. Fit the strengthening plate from inside the boot.
3. Tighten the nuts to meet the manufacturers specifications and road test the car.

