



PART NUMBER

PFF57-124

DESCRIPTION

TRANSMISSION MOUNTING BUSH

INSTALLATION GUIDE

Contents (parts per pack):

- | | |
|----------------------------|------------------|
| 2 x Polyurethane bushes | 1 x Steel Washer |
| 1 x Stainless steel sleeve | 1 x Grease |

Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;
 - all safety precautions adhered to;
 - wheel alignment to be checked and adjusted as required after any suspension work.
- All fasteners must be tensioned to manufacturer's torque settings.



Fitting Instructions:

1. Remove the original bush from the arm.
2. Clean any dirt and corrosion from the bore in the arm. Remove any sharp edges from the bore of the arm.
3. Insert bushes into bore of the arm.
4. Apply grease into bore of the bush and around top face. Fit sleeve into bush with featured spigot end of sleeve facing the transmission mount, as shown in *Figure 1*.
5. Place steel washer against outer polyurethane bush.
6. Re-fit arm to the car. Tension all hardware to manufacturers recommended torque settings.

Figure 1:

