

POWERFLEX®

PART NUMBER

PFR80-1216

DESCRIPTION

REAR LOWER ARM INNER BUSH

INSTALLATION GUIDE

Contents (parts per pack):

- 2 x bushes,
- 2 x metal sleeves
- 1 x grease



Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;
- all safety precautions adhered to;
- wheel alignment to be checked and adjusted as required after any suspension work.

All fasteners must be tensioned to manufacturer's torque settings.

Fitting Instructions:

1. Remove lower arm from the car, press out the original bush from arm. Be careful not to bend the arm or distort the two faces of the arm.
2. The new bush will need to be pressed into the arm, use a suitable adaptor to fit onto the metal of the outer shell so not pressing onto the polyurethane. Press the new bush into the arm until the larger diameter touches the arm.

Tip: Place a spacer between the two faces of the arm to stop the upper face from collapsing while pressing the bush through.

3. Apply some of the supplied grease into the bore of the bush and the outside of the stainless steel sleeve, fit the sleeve into the bush.
4. Refit the lower arm to the car.

